

These schematics cover the missing pages in the original ones published by the maker. Signal names existing in the original pages have been preserved. New signal names try to follow the maker style or are taken from similar schematics of the same maker.

The schematic shows a complex PCB layout for the Jotego board. It includes various components such as switches (SW1, SW2, SW3, SW_DIP_x08), resistors (RA 2.2Kx 4, RA 2.2Kx 8, R23, R25, R2, R1), and integrated circuits (74LS244, 74LS257, 74LS253, 74LS174, 051550). The board is connected to a Jamma connector (JM1) which provides power and control signals. The schematic also shows the internal connections of the ICs and the placement of various components on the PCB.

JOTEGO
www.patreon.com/jotego
KONAMI PWB351392A GX808
 Sheet: /
 File: mia.kicad_sch
Title: Missing In Action M.I.A
 Size: A3 Date: 2023-08-23 Rev: José Tejada G.
 KiCad E.D.A. 8.0.9 Id: 1/1